KENWOOD



Turn your mixer into so much more with a wide range of **ATTACHMENTS**

Kenwood is about helping you create more. A wide selection of attachments enables you to personalise your mixer to your needs. With three variable speed outlets, there's no task your stand mixer can't do - from a light and airy pavlova to that perfect homemade spaghetti.





The bowl tool outlet The bowl tool outlet is positioned above the bowl for all your whisking, mixing, kneading, creaming or folding needs as well as all your ice cream and sorbet cravings.





Slow speed

The slow speed outlet is used for attachments that require power without the high speed, such as the pasta attachment.






For those jobs that need power blitzing, the high speed outlet is perfect. Used with the blender attachment. it's ideal for those silky smooth soups and slicing and dicing.





Dial up the SALSA at your next dinner event

Make light work of food prep with Kenwood's Food Processor attachment. Chop meat, fish or vegetables. Six single slicing disks allow you to shred, slice, chop and rasp. Get those patés, dips and salsas on the table faster.



FOOD PROCESSOR KAH6500PL

Scan the QR code for more information.



Showcase your BURGER MAKING SKILLS

If you like to know exactly what goes into your meals, the Food Mincer attachment is for you. With fine, medium and coarse screens, it's perfect for grinding meat, vegetable or nuts. Make burgers, koftas and falafels.



FOOD MINCER KAX950ME

Scan the QR code for more information.

Start your day with a homegrown POWER BLEND



Wow the crowd with homemade SORBET



Homemade PASTA that would make Nonna *proud*.

Master the art of pasta making with Kenwoods pasta attachments. Create those favourites – lasagne, ravioli, cannelloni, fusili and so much more. With nine pasta thicknesses and twelve pasta dies, your only challenge is deciding which pasta to make!

PASTA CUTTERS



Spaghetti KAX984ME



Tagliolini KAX982ME



Trenette KAX983ME



Fettuccine KAX981ME



Pasta Shaper KAX92AOME AT91002 - AT910013 (Pasta dies) AT910014 (Biscuit maker)



RAVIOLI MAKER KAX93A0ME




LASAGNE ROLLER ATTACHMENT KAX980ME




Stand Mixer

ATTACHMENT GUIDE



Stand Mixer

ATTACHMENT GUIDE







Trenette KAX983ME

Spaghetti

KAX984ME



Fettuccine KAX981ME



Tagliolini KAX982ME

PASTA DIE ATTACHMENTS: (compatible with Pasta Shaper KAX92A0ME)



Silatelli AWAT910008





Spaccetelli AWAT910005



Bigoli AWAT910002



Conchigliette AWAT910011



Bucatini AWAT910012

Lisci



Spaghetti Quadri AWAT910006



Orecchiette AWAT910013



Fusilli AWAT910010



Biscuit Maker AWAT910014

Choose your recipe, choose your POPTOP

Kenwoods very first customisable Chef. You can change the top cover of your Titanium Chef Baker to complement your kitchen style, accessories, or even simply your recipe. Available in a range of colours, your Kenwood mixer can change as often as you want.





Scan the QR code for more information.



Add the *finishing* touches with the full DECORATING SET





Scan the QR code for more information.



Created in 2024.

Distributed By De'Longhi Australia Pty Ltd ABN 49 104 012 857 Po Box 4540 Casula Mall NSW 2170

Discover our full range of mixers, attachments and accessories, visit **kenwoodworld.com/en-au**

For customer care and sales information phone **1800 126 659**

Optional attachments and accessories can be purchased from selected retail stores or via the Kenwood Online Shop at **kenwoodworld.com**

To enquire about the warranty or servicing of Kenwood products, please visit **kenwoodworld.com**

Disclaimers: Due to a policy of continuous improvement, technical specifications and included attachments/accessories may change without prior notice.